

SEQUENCER / PROGRAMMER

DUAL GTS XL

GTO

DUAL GTS

ACTIVE PRO

VARIABLE Q VCF

XFADER

1 2 3 4 5 6 7 8

A B A-B GATE RESET UP / DOWN HOLD ON

A B CLOCK

IN BOTH 1V/O OUT SINE

VC VC END OUT TRI

RISE FALL TRIG IN PEAK IN PEAK TROUGH TROUGH IN

IN BOTH 1V/O OUT 2

VC VC END OUT SINE

RISE FALL TRIG IN PULSE SINE

VC 1V/O IN

HOLD COUPLER RUN SMPL INV

VC 1V/O OUT

RATE 1V/O IN

WHITE PINK S/H

1V/O TRIG TRIG

IN RISE IN

FALL RISE FALL

VC VC

RISE RISE

FALL FALL

OUT IN 1 IN 2 VC XFADE

FLIP FLOP IN

BAND HIGH NOTCH LOW

IN 2 AGC IN TRIG IN

LOW 1V/OCT

VC Q VC F

Q FREQ

OUT IN 1 IN 2 XFADE

1 2

GAIN